



Keyboard Port (XE Game System only):

----- 1 ----- 8
 ----- 00000000
 ----- 00000000
 ----- 9 ----- 15

1. KR2 Keyboard Response / 2. K3 Keyboard Scan / 3. K4 Keyboard Scan / 4. K5 Keyboard Scan / 5. KR1 Keyboard Response / 6. K0 Keyboard Scan / 7. K1 Keyboard Scan / 8. K2 Keyboard Scan / 9. Ground / 10. Not Connected / 11. Ground / 12. Not Connected / 13. Trigger 2 / 14. 5 VDC / 15. 5 VDC